



# BUG AND EAVESDROPPING DEVICE DETECTOR "BUGHUNTER PROFESSIONAL CR-01"



## RAPID SWITCHING-ON

- 1) Enable hidden tumbler switch by sliding it upward
- 2) Press ON button
- 3) Using the sensor panel slide a finger to the center of the scale

4) For even faster search press  
**“Operation mode” button**  
by pressing for over 3 sec.



- will start blinking

*Sound indication mode will be enabled*



3

5) Short press on **“Operation mode” button**  
will transfer the device between three modes:



*if the indicator is lit continuously – the device is in the mode of constant (analog) signal search*



*if the indicator blinks frequently – the device is in the mode of impulse (digital) transmitter search (digital eavesdropping devices, cell phones)*



*If the indicator is not lit and «AK» indicator lights up for a short time and goes out – the device is in Security mode (it will signal only when new sources radio signal appear in the room)*

